Rechargeable Battery Pack
USER'S GUIDE

PACKAGE CONTENTS:

- Rechargeable Battery
- USB Charge Cable
- User's Guide/Warranty Card
- Registration Card

for Wii Fit™

USING THE RECHARGEABLE BATTERY PACK:

1. Remove the original battery cover and any other batteries from your Wii Balance Board.
2. Insert the Rechargeable Battery Pack into the Wii Balance Board battery compartment by inserting the two locking tabs into the matching slots and pushing down. The Rechargeable Battery Pack will click into place securely.
3. To charge, plug the mini-USB end of the charging cable into the Rechargeable Battery Pack.
4. Plug the standard USB end of the charging cable into any available USB port on the Wii console or any other powered USB port.
4. The green LED light indicates that the Rechargeable Battery Pack is charging.
5. The red LED light indicates that the charge cycle is complete and the Rechargeable Battery Pack is ready for use.